RCP-100Ris a machine cleaner which removes all kinds of polymeric materials accumulated on roller of the dyeing machine.

*** SPECIFICATION**

* APPEARANCE Yellowish Liquid

* **IONIC NATURE** Nonionic * **SP.GR(at 25**°C) 1.25 ± 0.05

* **SOLUBILITY** Easily disperse in cold water.

* STORAGE STABILITY Min. 1 year under cool and dry conditions

when stored in original sealed, packaging.

* COMPATABILITY Compatible with anionic, nonionic and cationic materials.

USAGE AND PROCEDURE

- 1. Roller washing method after the color deepening process
- After putting on rubber gloves, thoroughly rub soiled parts of machines with RCP-100R on wet cloth.
- 2) Thoroughly wipe out stains of the machine, spraying water.
- 3) Rinse in water to remove RCP-100R completely.
- 4) If **RCP-100R** remains, color deepening efficiency may be degraded in use of a color deepening agent(DK-2002P).
- 5) It is environmental-friendly product as APEO-free and NPEO-free.
- 2. Washing method of the dyeing machine and the amount of use

Chemicals	Usage	Method
NaOH(98%)	5g/ℓ 3-	Washing with putting fiber and operating
RCP-100	5g/ℓ	Rapid dyeing machine during 135°C×60min

PACKAGE

200 Kgs NET IN DRUMS.

Cell No: +601116622841, E-mail: info@rochemint.com, www.rochemint.com